

SPIDER LIFT CMCS15 STARTING PROCEDURE

Ensure :-

The 3 red kill switch buttons are out

Green light by ignition key is lit

Red and green light on the basket control box are lit

TO RAISE AND LOWER LEGS

Turn the knob on the side of the removable control box to legs (anti clockwise)

TO OPERATE LIFT

Turn the knob on the side of the removable control box to lift (clockwise)

Before it will lift all leg pads must be under pressure and on the floor

To operate the lift from the basket ensure the ground control levers in the black metal box are locked so that they cannot be used.

To operate from the floor, unlock the levers in the black box

FOR ALL OTHER OPERATIONAL PROCEDURES READ THE OPERATING HANDBOOK STORED IN THE PLASTIC BOX IN THE BASKET.

ALWAYS WEAR FULL FALL HARNESS AND SAFETY HELMET.